

FIG-1




FIG. -3





FIG.-4

FIG-5A







FIG-5C






FIG-6




FIG-7

94

FIG-7A € 00 ر 08 96B 96C 91D 91E 98B 96A 97B <u>96</u> 98A 97A 91C С3 C1 91B **S**3 S2




FIG-8




FIG-9




FIG-10




FIG-11





FIG-11A






FIG-12




FIG-13




FIG-13A





FIG - 14



HIDE IN DRAWER (SEE FIG. 11), OR SET ON ANY SURFACE NEAR TELEVISION

ARCADE STYLE CONTROLS
ANYWHERE

FIG -15